

Functions:

This step counter records the number of steps taken (up to 99.999 steps).

How to wear :

Clip the step counter to your waistband or belt as shown in the picture below.

**How to use:**

Press the Reset button to zero and start walking. The step counter will start recording the number of steps taken. Press the Reset button again when you want to clear the result.

**Change of batteries:**

If the display begins to fade, please replace the battery by unscrewing the battery compartment. Remove the cover and replace the battery with the + Pol facing upward. Now close the compartment again and screw tightly.

